



# Waxing

The denture should be waxed to simulate the finished appliance as closely as possible.

### <u>Flasking</u>

A good grade of dental stone should be used. Soften the wax for removal and flush remaining wax residues from flask with boiling water containing a dye free, fragrance free, granular detergent. Then rinse with clean boiling water. Use no wax solvents. Apply Vita-Sep<sup>TM</sup> following instructions no. IN.723.009.R0.

### **Mixing**

Measure by volume, 3 parts of Vitacrilic<sup>®</sup> L-W powder to 1 part of crosslink monomer. The average size denture requires 30cc of powder to 10mL of monomer. **ALWAYS ADD POWDER TO LIQUID!** Mix vigorously for 15 to 30 seconds in a dry clean jar and keep in closed jar until ready to pack. The time necessary before proper packing consistency is approximately 15 minutes at 70° F and 10 minutes at 85° F. When material can be pulled away from the jar and is no longer sticky, knead material and roll into 1/2 inch diameter, several inches long. Place back in a clean closed jar. The mixed resin can be used for approximately 1/2 hour.

## <u>No Trial Pack</u>

Make sure Vita-Sep<sup> $^{\text{M}}$ </sup> is applied to both halves of flask, and dry before packing. Place the material in the mold carefully, using a polyethylene sheet around the fingers to prevent sticking. The dough is placed in the mold using an excess and the mold is closed without using a separating sheet. Close the mold applying pressure very slowly until the two halves make metal to metal contact, approximately 1 1/2 minutes should be required for full closure. Place the flask in compress. Allow to bench set for 15 minutes before curing.

### **Curing**

**Fast Cure**: Place compress in warm or room temperature water, heat to  $165^{\circ}$ F and hold at this temperature for 1 1/2 hours, transfer to boiling water and hold for 30 minutes. Bench cool for 30 minutes and place in cold water. **Slow Cure**: Place compress in warm or room temperature water, heat to  $165^{\circ}$  F for a minimum of 9 hours. Bench cool for 30 minutes and place in cold water. Deflask and finish in usual manner.

### **Repairs and Relines**

We recommend that color matched Vitacrilic<sup>®</sup> self-curing polymer and crosslink colorstable self-curing monomer be used for all repairs and relines.

**Caution:** Avoid prolonged handling of uncured mixture and inhalation of monomer vapors. Wear protective gloves when packing resin mixture.

FRICKE DENTAL INTERNATIONAL, INC. 165 Roma Jean Parkway Streamwood, IL 60107 800-537-4253 Visit our website at <u>www.frickedental.com</u> MADE IN THE USA